

Explosion Proof Blasting Light HID Blasting Gun Light - 20 Watt - Rechargeable - C1D1 Instruction Manual

Do not attempt operation until you are familiar with all warnings, precautions, and procedures outlined within this instruction sheet. Read carefully before operating. Retain these instructions for future reference.

WARNING:

- DO NOT MAINTAIN BLAST GUN LIGHT WITHIN A HAZARDOUS AREA.
 - ENSURE POWER SOURCE OUTPUTS THE CORRECT VOLTAGE. CHECK PRODUCT LABEL FOR PROPER VOLTAGE CONFIGURATION.
 - DO NOT STARE DIRECTLY INTO LIGHT WHILE POWERING ON.
 - DISCONNECT BLASTING EQUIPMENT PRIOR TO INSTALLATION TO PREVENT ACCIDENTAL ACTIVATION OF BLAST GUN.
 - MODIFYING ANY PART OF THIS LIGHT IS NOT RECOMMENDED AND WILL VOID WARRANTY.
-

INSTALLATION

MOUNTING TO BLAST GUN

Mount the U-bracket from the blasting light to any standard blasting gun, with U-bracket on bottom, as shown. Tighten nuts on top to hold in place.



OPERATION

Power for this blasting light is provided by an included rechargeable 4800mAh battery which gives this unit a run time of 140 minutes. The high intensity HID light produces 1200 lumens. A rubber push button switch provides easy operation and an aerospace grade aluminum housing provides excellent resistance to damage from impacts and vibrations. This unit is IP68 waterproof and able to withstand the rigors of aggressive and heavy duty use applications. Compared to typical gun mounted blasting lights, this compact HID unit offers freedom from electrical cords and produces much brighter and intense illumination than comparable incandescent lights.

USE AND CARE

Unauthorized modification may impair the function and/or safety of this device and could affect the life of the equipment. Always check for damaged or worn out parts before using the device. Store it in a secure place out of the reach of children when not in use. Inspect for good working condition prior to storage and before re-use.

REPLACEMENT PARTS

The BLG-HID is designed to provide years of reliable performance. Should the need for replacement parts arise, please contact Larson Electronics.

THESE INSTRUCTIONS MAY NOT COVER ALL DETAILS OR VARIATIONS OF THIS PRODUCT FOR YOUR EQUIPMENT OR INSTALLATION REQUIREMENTS. SHOULD FURTHER INFORMATION NOT COVERED BY THESE INSTRUCTIONS BE REQUIRED, PLEASE CONTACT LARSON ELECTRONICS BY EMAIL AT SALES@LARSONELECTRONICS.COM OR BY PHONE AT 1-877-348-9680 FOR FURTHER ASSISTANCE.

PLEASE VISIT LARSONELECTRONICS.COM FOR **WARRANTY** AND **RETURN** INFORMATION.