

Replacement Lens for SLEDB-110V Series 110 Volt LED Strobe Light Instruction Manual

Thank you for your purchase of the Larson Electronics SLEDB-110V-114 replacement lens. Please follow the steps below in order to operate and maintain this product.

IMPORTANT

READ CAREFULLY BEFORE OPERATING THIS FIXTURE. SAVE THESE INSTRUCTIONS FOR FUTURE REFERENCE. IF UNSURE ABOUT ANY PART OF THESE INSTRUCTIONS, CONSULT A QUALIFIED ELECTRICAL PROFESSIONAL.

WARNING: OPERATE ONLY AT THE VOLTAGE LISTED ON THE PRODUCT. DO NOT OPERATE IN CLOSE PROXIMITY OF COMBUSTIBLE OR FLAMMABLE MATERIALS. NEVER LOOK DIRECTLY AT LIGHT WHEN ON.

WARNING: CONSULT A QUALIFIED ELECTRICAL PROFESSIONAL/ELECTRICIAN TO INSTALL THIS DEVICE IN ACCORDANCE WITH APPROPRIATE LOCAL AND NEC CODES AND REGULATIONS.

WARNING: TO BE INSTALLED AND/OR USED IN ACCORDANCE WITH APPROPRIATE ELECTRICAL CODES AND REGULATIONS.

WARNING: DEVICE IS SUITABLE FOR INSTALLATION IN WET LOCATIONS; GFCI PROTECTION RECOMMENDED.

WARNING: ALTHOUGH FIXTURE IS WATERPROOF, IT IS NOT DESIGNED OR INTENDED TO BE SUBMERGED.

WARNING: DO NOT ALLOW LINE VOLTAGE WIRES TO BECOME SUBMERGED!

- ALL OUTDOOR INSTALLATIONS AND INDOOR INSTALLATIONS NEAR A WET LOCATION REQUIRE THE USE OF A GFCI DEVICE FOR SAFETY, ACCORDING TO THE NATIONAL ELECTRICAL CODE® (NEC).
- KEEP AWAY FROM FLAMMABLE OBJECTS. DO NOT POSITION WITHIN ONE (1) INCH OF ANY COMBUSTIBLE MATERIALS.
- IF DROPPED OR DAMAGED, THE UNIT MAY NO LONGER BE WATERPROOF AND SHOULD BE REPLACED.
- TO AVOID HAZARDS TO CHILDREN, ACCOUNT FOR ALL PARTS AND DESTROY PACKING MATERIALS.

INSTALLATION

Follow the steps below for installing and maintaining the strobe light.

1. Disconnect light from power source and let it cool down if disconnecting from mid-use.
2. Loosen four (4) screws at base of lens and carefully remove lens from base of unit.
3. Replace lens with desired replacement unit and secure lens using the four (4) screws loosened in step 2.
4. Reconnect light to power source and continue use as desired.

MAINTENANCE

Caution: To avoid personal injury, disconnect power to the light and allow the unit to cool down before performing maintenance.

Warning: No user serviceable parts inside of fixture. Risk of electric shock. Removal of the lens will void the warranty.

1. Perform visual, mechanical and electrical inspections on a regular basis. We recommend routine checks to be made on a yearly basis. Frequency of use and environment should determine this. It is recommended to follow an Electrical Preventive Maintenance Program as described in NFPA 70B: Recommended practice for Electrical Equipment.
2. The lens should be cleaned periodically as needed to ensure continued photometric performance. Clean the lens with a damp, non-abrasive, lint-free cloth. If not sufficient, use mild soap or a liquid cleaner.
3. Inspect the cooling fins on the luminaire to ensure that they are free of any obstructions or contamination (i.e. excessive dust build-up). Clean with a non-abrasive cloth if needed.
4. Do not operate if the lens is cracked or damaged. All fasteners should be properly seated.

USE AND CARE

Unauthorized modification may impair the function and/or safety of this device and could affect the life of the equipment. Always check for damaged or worn out parts before using the device. Store it in a secure place out of the reach of children when not in use. Inspect for good working condition prior to storage and before re-use.

REPLACEMENT PARTS

The SLEDB-110V-114 is designed to provide years of reliable performance. Should the need for replacement parts arise, please contact Larson Electronics.

THESE INSTRUCTIONS MAY NOT COVER ALL DETAILS OR VARIATIONS OF THIS PRODUCT FOR YOUR EQUIPMENT OR INSTALLATION REQUIREMENTS. SHOULD FURTHER INFORMATION NOT COVERED BY THESE INSTRUCTIONS BE REQUIRED, PLEASE CONTACT LARSON ELECTRONICS BY EMAIL AT SALES@LARSONELECTRONICS.COM OR BY PHONE AT 1-800-369-6671 FOR FURTHER ASSISTANCE.

PLEASE VISIT LARSONELECTRONICS.COM FOR **WARRANTY** AND **RETURN** INFORMATION.