Operating Instructions for 60 LED Corded Work Light Model WAL-DL-60LED-M

Electrical Rating - All models use 125 Volts 60 Hz


CAUTION: DO NOT use in explosive atmospheres, near flammable liquids, or where explosion proof lamps are required
DO NOT use in the proximity of vehicles or equipment when there is a risk of flammable liquids coming into contact with the handlamp
DO NOT immerse in water
DO NOT use in areas where water can accumulate or in rain or mist
CAUTION: Risk of Electric Shock – For Light Duty Dry Location Use Only

IMPORTANT SAFETY INSTRUCTIONS
This product has a polarized plug (one blade is wider than the other). As a safety feature, this plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless the plug can be fully inserted. Do not attempt to defeat this safety feature.

WARNING: NOT FOR USE ABOVE HAZARDOUS LOCATIONS

CAUTION: DO NOT USE IN HAZARDOUS LOCATIONS AS REQUIRED BY THE CANADIAN ELECTRICAL CODE, PART I

Thank you for purchasing this work light. Please read these instructions before using your work light. **Save these instructions.**



OPERATION

To operate, plug into a 120 Volt 60 Hz outlet. The work light has a two position rocker switch to activate the floodlight: or turn it off.

FEATURES

- The cord is 18 / 2 SJT cord with polarized 2 prong plug.
- 2116 = 6 ft cord, 2125 = 25 ft cord
- The magnetic hook can be attached at either the top of the light or on the side.
- The magnets can also be used to pick up small steel objects.

Model	Floodlight
WAL-DL-60LED-M	60 LED • 120 Lumens

SAFETY

CAUTION BRIGHT LED RADIATION: AVOID DIRECT EYE EXPOSURE. The light is a Class 2 LED product per IEC 60825-1 Edition 1.2.2001.

- Do not use this work light in explosive or hazardous areas.
- Do not attempt to repair or disassemble the work light. There are no user replaceable parts for this work light

WARRANTY

REQUEST FOR WARRANTY ACTION
If you have any questions about warranty or any other Larson Electronics product inquiries contact Larson Electronics.
Email: sales@larsonelectronics.com Phone: 1-800-369-6671

NOT COVERED
Warranty does not cover normal wear and tear or cosmetic damage. The Limited Warranty also does not cover damages which occurred in shipment or failures which are caused by accidents, misuse, abuse, faulty installation and lightning damage. Consequential damages, incidental damages or incidental expenses, including damage to property. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.