

Replacement Lens Kit for HAL-48-2L-LED-BMSW Series Instruction Manual

Do not attempt installation until you are familiar with all warnings and procedures outlined within this instruction sheet.

WARNING:

RETAIN THESE INSTRUCTIONS FOR FUTURE REFERENCE. CRITICAL SAFETY INSTRUCTIONS:

- BE CERTAIN ELECTRICAL POWER IS OFF BEFORE AND DURING MAINTENANCE.
-

INSTALLATION

We recommend a licensed electrician install and maintain this product.

Make sure power is disconnected prior to installing. Fixture must be mounted to a surface that can structurally support the load.

Mount following the steps below:

1. Open draw latches holding fixture lens. There are 5 latches on each side. Simply turn each latch counter-clockwise to loosen and unlatch from lens. Keep hold of lens and remove once free from draw latches.
2. Replace lens and close latches to secure. Place each latch into the slots on lens frame and turn clockwise to tighten.



DRAW LATCH

USE AND CARE

Always check damaged or worn out parts before using the light fixture. Broken parts will affect operation.

Should further information not covered by these instructions be required, please contact Larson Electronics at 1-800-369-6671 or sales@larsonelectronics.com for further assistance.

Please visit LarsonElectronics.com for **Warranty** and **Return** information.