Pneumatic Light Mast Bottom Mounting Plate
PLM-13.5 Series Pneumatic Light Masts
Instruction Manual

Do not attempt installation until you are familiar with all warnings, precautions, and procedures outlined within this instruction sheet.

WARNING:


READ CAREFULLY BEFORE INSTALLING FIXTURE. RETAIN THESE INSTRUCTIONS FOR FUTURE REFERENCE. CRITICAL SAFETY INSTRUCTIONS:

- INSTALLATION SHOULD ONLY BE CONDUCTED BY A QUALIFIED ELECTRICIAN IN ACCORDANCE WITH THE NATIONAL ELECTRIC CODE (NEC) AND ALL APPLICABLE FEDERAL, STATE AND LOCAL ELECTRIC CODES AND SAFETY STANDARDS.
- USE APPROPRIATE HARDWARE CAPABLE OF HOLDING BASE/MAST.

INSTALLATION

Using the predrilled holes, attach base to surface capable of supporting the weight. Once mounted, loosen bolts to remove front portion of both mounting clamps. Place pneumatic mast inside mount while threading electrical cable through hole at bottom of base. Once in place, replace mounting clamps removed earlier and tighten bolts.

With the mounting plate installed to surface and pneumatic mast securely attached, the tower is ready to be deployed. Install electrical connections/air hoses to complete the installation.





THESE INSTRUCTIONS MAY NOT COVER ALL DETAILS OR VARIATIONS OF THIS PRODUCT FOR YOUR EQUIPMENT OR INSTALLATION REQUIREMENTS. SHOULD FURTHER INFORMATION NOT COVERED BY THESE INSTRUCTIONS BE REQUIRED, PLEASE CONTACT LARSON ELECTRONICS BY EMAIL AT SALES@LARSONELECTRONICS.COM OR BY PHONE AT 1-800-369-6671 FOR FURTHER ASSISTANCE.

PLEASE VISIT LARSONELECTRONICS.COM FOR **WARRANTY** AND **RETURN** INFORMATION.