


Wiring Diagram

WARNING: DO NOT SERVICE WHILE ENERGIZED!

MT-DOE16-3P-208Y.120-45KVA-480D-N3R



PRIMARY VOLTS	
CONNECT LINES	VOLTAGE
X1, X2, X3	208
X0-X1, X0-X2, X0-X3	120

SECONDARY VOLTS	
CONNECT LINES TO H1, H2, H3	
CONNECT	VOLTAGE
1	504
2	492
3	480
4	468
5	456
6	444
7	432