


Wiring Diagram

WARNING: DO NOT SERVICE WHILE ENERGIZED!

MMT-415V-500VA-220V



High Voltage (HV)
(INPUT)
415

Install Supplied Jumpers
Between Terminals
NONE

Lines
Connect to
2, 6

Low Voltage (LV)
(OUTPUT)
220

Install Supplied Jumpers
Between Terminals
3-4

Lines
Connect to
2, 5