
Wiring Diagram

WARNING: *DO NOT SERVICE WHILE ENERGIZED!*

MT-ATX-3P-380D-9KVA-208Y.120-N3R



Primary Volts	Connect Lines To	Inter-connect
380	H1, H2, H3	1
361	H1, H2, H3	2
342	H1, H2, H3	3

Secondary Volts	Connect Lines To	Inter-connect
208	X1, X2, X3	-
120 1 phase	X1 to X0 X2 to X0 X3 to X0	-

LARSON ELECTRONICS LLC • 9419 E US HWY 175 • KEMP, TX 75143
p: 1-800-369-6671 • intl: 903-498-3363 • f: 903-498-3364 • sales@larsonelectronics.com