




Wiring Diagram

WARNING: DO NOT SERVICE WHILE ENERGIZED!

MT-ATX-1P-480V-10KVA-240V-N3R



High Voltage Connections

H Volts	480
Interconnect	H2 - H3
HV Lines	H1 - H4

Low Voltage Connections

L Volts	240
Interconnect	X2 - X3
LV Lines	X1 - X4