


## Wiring Diagram

**WARNING:** DO NOT SERVICE WHILE ENERGIZED!

### MMT-208V-1000V-120V

Primary: 208V  
Secondary: 120V



| Connections     |                               |
|-----------------|-------------------------------|
| Primary Volts   | Primary Lines<br>Connect To   |
| 208             | H1 - H2                       |
| Secondary Volts | Secondary Lines<br>Connect To |
| 120             | X1 - X2                       |