
Wiring Diagram

WARNING: *DO NOT SERVICE WHILE ENERGIZED!*

MT-DOE16-FP-1P-120V.240-5KVA-240V-N3R



Primary Volts	Connect Lines To	Connection Each Phase
277	H1-H2	1-2
240	H1-H2	3-4
208	H1-H2	5-6
120	H1-H2	7-8

Secondary Volts	Connect Lines To	Inter-connect
240	X1-X4	X2-X3
120/240	X1-X2-X4	X2-X3
120	X1-X2	X1-X3, X2-X4

LARSON ELECTRONICS LLC • 9419 E US HWY 175 • KEMP, TX 75143
p: 1-800-369-6671 • intl: 903-498-3363 • f: 903-498-3364 • sales@larsonelectronics.com