


Wiring Diagram

WARNING: DO NOT SERVICE WHILE ENERGIZED!

MT-ISX-FP-1P-400V-7.5KVA-230V-N3R



Primary Volts	Connect Lines To	Connect Taps
400	H1-H10	H2-H9

Secondary Volts	Connect Lines To	Connect
230	X1-X4	X2-X3