


Wiring Diagram

WARNING: DO NOT SERVICE WHILE ENERGIZED!

MMT-277V-50VA-120V



Connections

Primary Volts	Primary Lines Connect To
277	H1 - H2
Secondary Volts	Secondary Lines Connect To
120	X1 - X2