


Wiring Diagram

WARNING: DO NOT SERVICE WHILE ENERGIZED!

MT-DOE16-3P-208D-75KVA-400Y.231-N3R



COIL TAP ARRANGEMENT

4	2	3
7	5	6
7	8	9

4	2	3
7	5	6
7	8	9

4	2	3
7	5	6
7	8	9

PRIMARY VOLTS	
CONNECT LINES TO X1, X2, X3	
TAP	VOLTAGE
9	208
SECONDARY VOLTS	
CONNECT LINES TO	VOLTAGE
H1, H2, H3	400
H1, H0 H2, H0 H3, H0	231 - 1Phase