


Wiring Diagram

WARNING: DO NOT SERVICE WHILE ENERGIZED!

MT-ISX-3P-480D-6KVA-690D-N3R



PRIMARY VOLTS	
CONNECT LINES TO X1, X2, X3	
TAP	VOLTAGE
1	480
2	456
3	432

SECONDARY VOLTS	
CONNECT LINES	VOLTAGE
H1, H2, H3	690