
Wiring Diagram

WARNING: *DO NOT SERVICE WHILE ENERGIZED!*

MT-ISX-FP-1P-240V-5KVA-120.240V-N3R-50HZ



Primary Volts	Connect Lines To	Inter-connect
240	H1-H4	H2-H3
120	H1-H4	H1-H3, H2-H4

Secondary Volts	Connect Lines To	Inter-connect
240	X1-X4	X2-X3
120/240	X1-X2-X4	X2-X3
120	X1-X2	X1-X3, X2-X4

LARSON ELECTRONICS LLC • 9419 E US HWY 175 • KEMP, TX 75143
p: 1-800-369-6671 • intl: 903-498-3363 • f: 903-498-3364 • sales@larsonelectronics.com