


Wiring Diagram

WARNING: DO NOT SERVICE WHILE ENERGIZED!

MMT-120V-250VA-80V



Primary Volts	Connect Lines To	Interconnect
120	H1-H2	-

Secondary Volts	Connect Lines To	Interconnect
80	X1-X4	X2-X3
40	X1-X4	X2-X4, X1-X3