


Wiring Diagram

WARNING: DO NOT SERVICE WHILE ENERGIZED!

MT-DOE16-3P-480D-75KVA-220D.110CT-N3R

Primary: 480 Volts Delta
Secondary: 220 Volts Delta



Connections

Primary Volts	On Each Coil Jumper Taps To	Primary Lines Connect To
480	3	H1, H2, H3
Secondary Volts	Secondary Lines Connect To	
220	X1, X2, X3	