



Wiring Diagram

WARNING: DO NOT SERVICE WHILE ENERGIZED!

MT-DOE16-FP-1P-480V-5KVA-120.240V-N3R

Primary Volts	Connect Lines To	Bridging
480	H1-H2	1-4/2-3

Secondary Volts	Connect Lines To
240	X1-X3
120	X1-X2