


Wiring Diagram

WARNING: DO NOT SERVICE WHILE ENERGIZED!

MT-ISX-3P-600D-6KVA-120Y.69-N3R

SCHEMATIC	CONNECTIONS	
	Primary Volts	Connect lines to
	600	H1, H2, H3
	Secondary Volts	Connect lines to
	120Y/69	X1, X2, X3