

Wiring Diagram

WARNING: DO NOT SERVICE WHILE ENERGIZED!

EPH-FH-T3B-5KW-480.3P

Supply Voltage: Nominal 480V 3-Phase

