




Wiring Diagram

WARNING: DO NOT SERVICE WHILE ENERGIZED!

MMT-415V-500VA-110V



High Voltage (HV)
(INPUT)
415

Install Supplied Jumpers
Between Terminals
3-4

Lines
Connect to
2, 5

Low Voltage (LV)
(OUTPUT)
110

Install Supplied Jumpers
Between Terminals
2-3, 4-5

Lines
Connect to
2, 5