




Wiring Diagram

WARNING: DO NOT SERVICE WHILE ENERGIZED!

MMT-480V-750VA-380V



Connections

Primary Volts	Primary Lines Connect To
480	H1 - H2
Secondary Volts	Secondary Lines Connect To
380	X2 - X1