


Wiring Diagram

WARNING: DO NOT SERVICE WHILE ENERGIZED!

MT-CTX-120V-35VA-30V



Primary Volts	Connect Lines To
120	H1, H2

Secondary Volts	Connect Lines To
30	X1, X2