

Wiring Diagram

WARNING: DO NOT SERVICE WHILE ENERGIZED!

MULTI-ATTEMPT AUTOMATIC ENGINE CONTROL MODULE

