


Wiring Diagram

WARNING: DO NOT SERVICE WHILE ENERGIZED!

MT-CTX-120V-0.05KVA-240V



INPUT (X)	LINES	INTERCONNECT
120V	X1-X4	X4-X2, X3-X1

OUTPUT (H)	LINES	INTERCONNECT
240V	H1-H4	H4-H2, H3-H1