


Wiring Diagram

WARNING: DO NOT SERVICE WHILE ENERGIZED!

MT-DOE16-3P-600D-45KVA-208Y.120-N3R



COIL TAP ARRANGEMENT

8	7	6
5	4	3
2	1	0

PRIMARY VOLTS	
CONNECT LINES TO H1, H2, H3	
TAP	VOLTAGE
2	629
3	616
4	600
5	585
6	569
7	556
8	540
SECONDARY VOLTS	
CONNECT LINES	VOLTAGE
X1, X2, X3	208
X0-X1, X0-X2, X0-X3	120