




Wiring Diagram

WARNING: DO NOT SERVICE WHILE ENERGIZED!

MT-CTX-380V-250VA-220V-50HZ



INPUT VOLTAGE

380V CONNECT: H1-H3

OUTPUT VOLTAGE

220V CONNECT: X1-X4