
Wiring Diagram

WARNING: *DO NOT SERVICE WHILE ENERGIZED!*

MT-ISX-SS-FP-1P-480V-25KVA-120.240V-N4X



Primary Volts	Connect Lines To	Interconnect
480	H1-H4	H2-H3
240	H1-H4	H1-H3, H2-H4
CONNECT TAPS 3-4		

Secondary Volts	Connect Lines To	Interconnect
240	X1-X4	X2-X3
120/240	X1-X2-X4	X2-X3
120	X1-X4	X1-X3, X2-X4

LARSON ELECTRONICS LLC • 9419 E US HWY 175 • KEMP, TX 75143
p: 1-800-369-6671 • intl: 903-498-3363 • f: 903-498-3364 • sales@larsonelectronics.com