


Wiring Diagram

WARNING: DO NOT SERVICE WHILE ENERGIZED!

MT-DOE16-FP-3P-115D-6KVA-200Y.115-N3R-400HZ



PRIMARY VOLTS	
CONNECT LINES TO X1, X2, X3	
TAP	VOLTAGE
1	120
2	115
3	109

SECONDARY VOLTS	
CONNECT LINES	VOLTAGE
H1, H2, H3	200
H0-H1, H0-H2, H0-H3	115