

Wiring Diagram

WARNING: *DO NOT SERVICE WHILE ENERGIZED!*

MT-ISX-3P-240Y-30KVA-400Y.231-N3R-50HZ



COIL TAP ARRANGEMENT



PRIMARY VOLTS	
CONNECT LINES TO X1, X2, X3	
CONNECT TAPS	VOLTAGE
2	254
3	247
4	240
5	234
6	228
7	222
8	214
9	208
10	201
SECONDARY VOLTS	
CONNECT LINES TO	VOLTAGE
H1, H2, H3	400
H1, H0 | H2, H0 | H3, H0	231

LARSON ELECTRONICS LLC • 9419 E US HWY 175 • KEMP, TX 75143
p: 1-800-369-6671 • intl: 903-498-3363 • f: 903-498-3364 • sales@larsonelectronics.com