

Wiring Diagram

WARNING: DO NOT SERVICE WHILE ENERGIZED!

MT-CTX-600V-150VA-240V

