


Wiring Diagram

WARNING: DO NOT SERVICE WHILE ENERGIZED!


MT-ISX-3P-380D-65KVA-208D-N3R-SP4132-R4

Input Voltage: 380V (H)

Output Voltage: 208V (X)



COIL TAP ARRANGEMENT



PRIMARY VOLTS	
CONNECT LINES TO	VOLTAGE
H1, H2, H3	380
SECONDARY VOLTS	
CONNECT LINES TO X1, X2, X3	
CONNECT TAPS	VOLTAGE
2	254
3	249
4	240
5	233
6	229
7	223
8	208
9	202