


Wiring Diagram

WARNING: DO NOT SERVICE WHILE ENERGIZED!

MT-DOE16-1P-380V-15KVA-220.110V-N3R-50HZ



Primary Volts	Connect Lines To	Inter-connect
380	H1, H2	

Secondary Volts	Connect Lines To	Inter-connect
220	X1, X4	X2-X3
110/220	X1-X2-X4	X2-X3
120	X1, X4	X1-X3, X2-X4