


Wiring Diagram

WARNING: DO NOT SERVICE WHILE ENERGIZED!

MT-DX-3P-460D-34KVA-230Y.133-N3R



PRIMARY VOLTS	
CONNECT LINES TO H1, H2, H3	
TAP	VOLTAGE
3	460

SECONDARY VOLTS	
CONNECT LINES	VOLTAGE
X1, X2, X3	230
X0-X1, X0-X2, X0-X3	133