


## Wiring Diagram

**WARNING: DO NOT SERVICE WHILE ENERGIZED!**

### MT-ISX-FP-3P-208D-1KVA-480D-N3R



| PRIMARY VOLTS |         |
|---------------|---------|
| CONNECT LINES | VOLTAGE |
| X1, X2, X3    | 208     |

| SECONDARY VOLTS             |         |
|-----------------------------|---------|
| CONNECT LINES TO H1, H2, H3 |         |
| TAP                         | VOLTAGE |
| 1                           | 480     |
| 2                           | 456     |
| 3                           | 432     |