


Wiring Diagram

WARNING: DO NOT SERVICE WHILE ENERGIZED!

MT-CTX-240.480V-50VA-9.18.24V



Primary Volts	Connect Lines To	Interconnect
240	H1-H4	H1-H3, H2-H4
480	H1-H4	H2-H3

Secondary Volts	Connect Lines To
9	X1-X2
18	X1-X3
24	X1-X4