


## Wiring Diagram

**WARNING:** DO NOT SERVICE WHILE ENERGIZED!

### MT-CTX-277V-100VA-208V



#### Connections

| Primary Volts   | Primary Lines<br>Connect To   |
|-----------------|-------------------------------|
| 277             | H1 - H4                       |
| Secondary Volts | Secondary Lines<br>Connect To |
| 208             | X1 - X4                       |