


Wiring Diagram


WARNING: DO NOT SERVICE WHILE ENERGIZED!

MT-PML-R20-1P-GMQ-75KVA-SLT-LT-DF-Z6-BB-CZ-1B2-M1




PRIMARY VOLTS	
CONNECT LINES TO H1A, H1B	
TAP	VOLTAGE
1	7620

SECONDARY VOLTS	
CONNECT LINES	VOLTAGE
X1, X3	480
X1, X2	240



Wiring Diagram

MT-PML-R20-1P-GMQ-75KVA-SLT-LT-DF-Z6-BB-CZ-1B2-M1



Wiring Diagram

WARNING: DO NOT SERVICE WHILE ENERGIZED!

MT-PML-R20-1P-GMQ-75KVA-SLT-LT-DF-Z6-BB-CZ-1B2-M1

