

Wiring Diagram

WARNING: DO NOT SERVICE WHILE ENERGIZED!

MT-BBT-575V-460V-30A




DIAGRAM
CONNECTION GUIDE

1. Connect X4 and X2 together
2. Connect X3 and X1 together
3. Connect High Voltage L1 to X4, X2
4. Connect Low Voltage L1 to X1, X3, H8
5. Connect H5 and H4 together
6. Connect High & Low Voltage L2 to H1

LOW REFERS TO THE LOWER VOLTAGE
HIGH REFERS TO THE HIGHER VOLTAGE