




Wiring Diagram

WARNING: DO NOT SERVICE WHILE ENERGIZED!

MT-CTX-690V-40VA-230V



Connections

Primary Volts	Primary Lines Connect To
690	H2 - H3
Secondary Volts	Secondary Lines Connect To
230	X2 - X3