


Wiring Diagram

WARNING: DO NOT SERVICE WHILE ENERGIZED!

MT-ISX-FP-3P-208D-3KVA-380D-N3R



PRIMARY VOLTS	
CONNECT LINES TO X1, X2, X3	
TAP	VOLTAGE
1	208

SECONDARY VOLTS	
CONNECT LINES	VOLTAGE
H1, H2, H3	380