


Wiring Diagram

WARNING: DO NOT SERVICE WHILE ENERGIZED!

MT-ISX-FP-1P-208V-15KVA-230V.EU-N3R



Primary Volts	Connect Lines To	Interconnect
208	H1-H6	H2-H5

Secondary Volts	Connect Lines To
230	L-N