


Wiring Diagram

WARNING: DO NOT SERVICE WHILE ENERGIZED!

MT-ISX-500D-9.06KVA-480D-3P-N3R



PRIMARY VOLTS	
CONNECT LINES TO H1, H2, H3	
TAP	VOLTAGE
1	COM
1-2	500
1-3	492
1-4	480
1-5	468
1-6	456
1-7	444
1-8	432

SECONDARY VOLTS	
CONNECT LINES	VOLTAGE
X1, X2, X3	480