


Wiring Diagram

WARNING: DO NOT SERVICE WHILE ENERGIZED!

MT-CTX-690V-50VA-24V



Connections

Primary Volts	Primary Lines Connect To
690	H1 - H4
Secondary Volts	Secondary Lines Connect To
24	X1 - X4