


Wiring Diagram

WARNING: DO NOT SERVICE WHILE ENERGIZED!

MT-CTX-120V-100VA-4.5V



Connections

Primary Volts	Primary Lines Connect To
120	H1 - H4
Secondary Volts	Secondary Lines Connect To
4.5	X1 - X4