



Wiring Diagram

WARNING: DO NOT SERVICE WHILE ENERGIZED!

MT-ISX-FP-1P-450V-10KVA-120V-N3R

Primary Volts	Connect Lines To	BRIDGING
450V	H1-H2	7-8

Secondary Volts	Connect Lines To
120V	X1-X2