


Wiring Diagram

WARNING: DO NOT SERVICE WHILE ENERGIZED!

MMT-480-30VA-48V



Connections

Primary Volts	Primary Lines Connect To
480	H2 - H3
Secondary Volts	Secondary Lines Connect To
48	X2 - X3