


Wiring Diagram

WARNING: DO NOT SERVICE WHILE ENERGIZED!

MT-CTX-480V-20VA-220V



Connections

Primary Volts	Primary Lines Connect To
480	H1-H2
Secondary Volts	Secondary Lines Connect To
220	X2-X1