


Wiring Diagram

WARNING: DO NOT SERVICE WHILE ENERGIZED!

MT-CTX-69V-20VA-120V



Connections

Primary Volts	Primary Lines Connect To
69	X1-X2
Secondary Volts	Secondary Lines Connect To
120	H2-H1